

**Latest Firmware version issued on July, 7<sup>th</sup>, 2017**  
**Retevis RT82(GPS-REC)-S3.33.bin for GPS version**  
**Retevis RT82(REC)-D3.33.bin for common version**


**Programming software: V1.16**

**Note: please kindly note that you should use the correct firmware and you should operate the updating in correct way, or radio will be in chaos like following photo**



- 1、 Address the issue of receiving in the repeater mode, if the upper and lower frequency are the same and one use slot 1 and the other use slot 2, there will be no signaling coming
- 2、 Address the issue of same channel cannot be added into different band in the same zone
- 3、 Releasing the new programming software can read the codeplug from RT3
- 4、 Adding the monitor in the analog mode
- 5、 Address the issue of dual standby, if the upper or lower has the signal with carrier, another one didn't have audio out
- 6、 Address the programming issue, sometimes, the radio will restart during programming

Press PTT and alarm key( on the top) to turn on the radio, the indicator blinks and open upgraded software



And then write upgraded file into radio, the radio will be upgraded as following:

